

Assembly Instructions for Devon Picnic Bench 1.8m

Contents

Fixings	Components	Tools Required
(1) 12 x M10 x 65mm Coach Bolts	(A) 2 x Seat Supports <input type="checkbox"/>	17mm Socket or Box Spanner
(2) 4 x M8 x 65mm Coach Bolts	(B) 2 x Pairs of Legs <input type="checkbox"/>	13mm Socket or Box Spanner
(3) 12 x M10 x Nuts and Washers	(C) 1 x Table Top <input type="checkbox"/>	Philips Screwdriver
(4) 4 x M8 Nyloc Nuts and Washers	(D) 2 x Seats <input type="checkbox"/>	<input type="checkbox"/>
(5) 6 x 60mm Woodscrews	(E) 2 x Table Braces <input type="checkbox"/>	<input type="checkbox"/>

Before you start

- It will take **two** people to assemble this product
- Check to make sure you have all of the parts listed above. If not call our helpline
- Assemble in a clear, level area.
- Only tighten fully when all components are aligned in place
- Always sight on firm level ground




Diagram 1

Taking 1 x seat support (A) place 4 x fixings (1) through pre-drilled holes.

Turn and face upwards. Place 1 x left hand leg and 1 x right hand leg with countersink in the legs facing upwards as per Diagram 1 and fix using 4 x fixings (3).

Repeat for second leg assembly..




Diagram 2

Lay table top (C) face-down on a clean flat surface and place 1 x leg assembly to the inside of table end bearer and fix using 2 x fixings (1) and 2 x fixings (3).

Repeat for second leg assembly..




Diagram 3

Place table leg brace (E) against seat support (A) and underside of table top (C) and fix using 6 x fixings (5).

THIS PICNIC BENCH SHOULD NOT BE USED WITHOUT THESE TABLE BRACES BEING FITTED.

Turn table over at this point. (**Note** Heavy weight - use at least two people).




Diagram 4

Position seat (D) over seat supports (A) and fix using 4 x fixings (4).

Care and Maintenance

Your new garden furniture is a natural timber product. In order that you may prolong the life of this product, we recommend that you follow the general care and maintenance advice below.

The timber used in the Devon Range furniture is pressure treated in accordance with BS 8417:2011 to provide protection against biodeterioration in end use situations. It is possible that under some environmental conditions that a surface mould may develop, should this happen clean off with mild soapy water.

All fixings to be checked for tightness and signs of deterioration at the beginning of each season and on a regular basis.

We recommend that this product is positioned on firm level ground. If necessary the product can be firmly fixed to the ground by using a proprietary ground anchor.

Product should be checked regularly, and re-coated with a suitable topcoat finish when required. If accidental damage occurs, lightly sand and re-coat with a suitable water based wood preservative. Product can be cleaned periodically with a mild soapy detergent.

This is a natural product and therefore colour may vary slightly from piece to piece.

As a natural product it is possible that knots can work loose and sometimes fall out, also resin leakage and small cracks can appear on the woods surface. Should this happen, clean of resin, ensure any sharp edges are sanded smooth and recoat.

Products should be given suitable protection from adverse weather conditions, particularly during the winter months.

Please retain these instructions for future reference and use.

